



# The Resource Prospector Near-Infrared Volatile Spectrometer System NIRVSS

Anthony Colaprete  
NASA Ames Research Center

T. L. Roush, A. Cook, R. Bielawski,  
E. Fritzler, J. Benton, J. Forgione, R.  
McMurray, B. White








# Why NIR Spectroscopy?



- Proven Technique
- Provides information on a range of solid volatiles, but also mineralogy
- Can provide additional information on the form (e.g., crystalline vs. amorphous ice) and grain size
- Instrumentation can have a relative small Project and Mission “foot print”, including low cost, mass, volume and power
- Can provide rapid evaluation of samples for cortical decision making









# What Wavelengths and Resolutions?



*RESOLVE: Regolith & Environment Science and Oxygen & Lunar Volatile Extraction*

## Volatile search

- Species include:  $\text{H}_2\text{O}$ ,  $\text{NH}_3$ ,  $\text{CO}_2$ ,  $\text{CH}_4$
- Ample vibrational fundamental absorptions at near- to shortwave-infrared wavelengths (1.5-4  $\mu\text{m}$ )
- Spectral resolution required:
  - $\text{H}_2\text{O}$ : 20-30 nm
  - $\text{NH}_3$ : 10-20 nm
  - $\text{CO}_2$ : 10-20 nm
  - $\text{CH}_4$ : 20-30 nm







# What Wavelengths and Resolutions?







**RESOLVE: Regolith & Environment Science and Oxygen & Lunar Volatile Extraction**

NIRVSS Range **NIRVSS**

## Volatile search

- Species include:  $\text{H}_2\text{O}$ ,  $\text{NH}_3$ ,  $\text{CO}_2$ ,  $\text{CH}_4$
- Ample vibrational fundamental absorptions at near- to shortwave-infrared wavelengths (1.5-4  $\mu\text{m}$ )
- Spectral resolution required:
  - $\text{H}_2\text{O}$ : 20-30 nm
  - $\text{NH}_3$ : 10-20 nm
  - $\text{CO}_2$ : 10-20 nm
  - $\text{CH}_4$ : 20-30 nm






# How Sensitive to H<sub>2</sub>O Ice?



**RESOLVE: Regolith & Environment Science and Oxygen & Lunar Volatile Extraction**



Ice ( $\mu\text{m}$ )	Soil ( $\mu\text{m}$ )	BD <sub>2000</sub> (%)	SNR, 3 $\sigma$	BD <sub>3000</sub> (%)	SNR, 3 $\sigma$
10	10	5.0	49	20.1	14.5
10	70	4.0	75	19.4	15
70	70	3.5	86	2.7	111
200	70	2.9	103	0.6	500



# NIRVSS - Science Goals



*RESOLVE: Regolith & Environment Science and Oxygen & Lunar Volatile Extraction*

1. **Monitor** the surface during rover traverses and at excavation sites for water and other volatiles.
  - Identify surface bound  $\text{H}_2\text{O}/\text{OH}$
  - Constrain mineralogical/geological context
  - Measure surface temperatures
  
2. **Observe** the immediate vicinity of the drill site before and during drill operations to look for near real-time changes in the properties of the exposed materials.
  - Identify volatiles, including water form (e.g., ice vs. bound)
  - Identify gasses evolved during drilling activity
  - Constrain the volatile presence in top ~20-30 cm of regolith:  
provides constraints on neutron measurements of H-abundance
  - Constrain surface/subsurface temperatures


# NIR Volatiles Spectrometer System



Spectrometer




Bracket Assembly



Lamp  
Assembly

Drill Ops Camera  
(DOC)



Fiber Optics to  
Spectrometers

LCS

LEDs

No ITAR/EAR export

Key instrumental characteristics for NIRVSS, Bracket Assembly

Property	Spectrometer	NIRVSS Bracket Assembly		
	NIRVSS	Lamp	DOC	LCS
Size (mm)	202 x 154 x 82	204 x 130 x 151		
Mass (kg)	1.97	1.14		
Native Resolution	N/A	N/A	2048 x 2048	N/A
Image Scaling Options	N/A	N/A	2048 x 2048, 1024 x 1024, 512 x 512, 256 x 256, 128 x 128	N/A
Wavelength range, sampling, (nm)	1.6-2.4, 0.009 2.3-3.4, 0.012	N/A	410, 540, 640, 740, 905, 940, 1025 nm	8, 10.6, 14, 25
Power (W)		BA Electronics: 1.68 (n), 1.75 (p)		
Nominal (n):	6.8	12.3	0.3 (n) 1.0 (p),	0.28
Peak (p):	7.4		7.14 (LED flash)	
IFOV, (°)	≈24° each	≈26°	camera, 55° LEDs, 90-100°	≈35°
Thermal (°C)				
Survival:	-25 > T > +75	-50 > T > +120	-30 > T > +70	-30 > T > +70
Operational:	-20 > T > +45	-20 > T > +110	-20 > T > +60	-20 > T > +60
Data Interface, rate (kbaud)	2 - RS-422, 115.2	NA	RS-422, 230.4	RS-422, 9.6
Input Voltage	28 +/- 6V	28 +/- 6V		






# NIRVSS Components



**RESOLVE: Regolith & Environment Science and Oxygen & Lunar Volatile Extra**

## Spectrometer

- Sufficient wavelength range and resolution to identify key volatiles (solid and gas)
  - 2 optical Engines; ShortWave (SW)  $\approx 1600\text{-}2400$  nm and LongWave (LW)  $\approx 2300\text{-}3400$  nm
  - Spectral sampling SW  $\approx 9$  nm LW  $\approx 12$  nm
  - Full spectrum approximately every 0.7 sec
- Achieve SNR  $> 100$  at  $2\text{ }\mu\text{m}$  and  $3\text{ }\mu\text{m}$  while roving and drilling



## Bracket Assembly

- IR emitter
  - Enables observations while roving and drilling, in dark
  - Bright enough to meet SNR requirement while in shadow
- Drill Observation Camera (DOC)
  - Image drill area with sufficient FOV to observe cuttings
  - Sufficient resolution to identify 0.15 mm regolith structure
  - 8 LEDs for multi-spectral imaging
- Longwave Calibration Sensors (LCS)
  - thermal emission correction for  $3\text{ }\mu\text{m}$  band; required for determining concentrations of OH/H<sub>2</sub>O
  - Measure radiance at 8, 10, 14 and 25  $\mu\text{m}$







# NIRVSS Testing




**RESOLVE: Regolith & Environment Science and Oxygen & Lunar Volatile Extraction**



RP15 Porotype rover with payload



RP15 Remote Ops at ARC



GRC VF13 TVAC Chamber



# NIRVSS Testing



**RESOLVE: Regolith & Environment Science and Oxygen & Lunar Volatile Extraction**

RP15 Rover Testing



GRC TVAC Testing








# NIRVSS – GRC Drilling Tests



**RESOLVE: Regolith & Environment Science and Oxygen & Lunar Volatile Extraction**







# NIRVSS - Summary



**RESOLVE: Regolith & Environment Science and Oxygen & Lunar Volatile Extraction**

- NIRVSS spectrometer & illumination source provide sensitivity to changes in soil water content while roving and as drilling progresses
  - Can provide a “quick” assay of drill cuttings for volatile content
- Relatively modest “footprint” at around 3kg and 15W
- NIRVSS DOC captures morphology and behavior during drilling and LEDs provide compositional recognition
- NIRVSS LCS designed for correction of surface T's  $> 200^{\circ}$  K, and can measure the scene temperatures between 80 to 400 K